Extraflame®

Riscaldamento a Pellet

DIADEMA - LILIANA IDRO IDRO

USER MANUAL

ENGLISH/INGLESE

We thank you for having chosen our company; our product is a great heating solution developed from the most advanced technology with top quality machining and modern design, aimed at making you enjoy the fantastic sensation that the heat of a flame gives, in complete safety.

ENGLISH 5

WARNINGS **5**
SAFETY **5**
ROUTINE MAINTENANCE **5**
HYDRAULIC SYSTEM **6**
INSTALLATION AND SAFETY DEVICES 6
SAFETY DEVICES FOR CLOSED VESSEL SYSTEM 6
DISTANCES OF SAFETY DEVICES ACCORDING TO THE STANDARD 6
TYPE OF SYSTEM **7**
CLOSED VESSEL PLANT 7
SAFETY VALVES 7
CLOSED EXPANSION VESSEL 8
COMMISSIONING CHECKS 8
AUTOMATIC THERMOSTATIC MIXER VALVE (MANDATORY) 8
LILIANA IDRO - DIADEMA IDRO BASIC HYDRAULIC SYSTEM DIAGRAM **9**
STOVE POSITIONING 10
REARMS **10**
FEATURES **10**
DEVICES **11**
REFERENCE STANDARDS **11**
GENERAL 12
INSTALLATION **13**
FUMES EXHAUST SYSTEM **14**
GENERAL REQUIREMENTS 14
SMOKE DUCT 15
CHIMNEY 17
CHIMNEY CAPS 17
FUMES EXHAUST SYSTEM PRODUCT REQUIREMENTS 18
COMBUSTION PRODUCTS OUTLET QUOTA 18
TECHNICAL INSTALLATION DOCUMENTATION 19
PELLETS AND FEEDING **20**

INDEX

CONTROL PANEL **21**
DISPLAY ICONS KEY 21
GENERAL MENU **22**
BASIC INSTRUCTIONS 22
THE REMOTE CONTROL **23**
ENABLE DELAYED SWITCH-OFF 23
TYPE AND REPLACEMENT OF BATTERIES 23
COMMISSIONING SETTINGS **24**
ADJUSTING TIME, DAY, MONTH AND YEAR 24
ADJUSTING THE LANGUAGE 24
OPERATION AND LOGIC **25**
ADDITIONAL ROOM THERMOSTAT **26**
ADDITIONAL THERMOSTAT FUNCTIONING WITH STBY ACTIVE 26
ADDITIONAL THERMOSTAT FUNCTIONING WITH STBY DEACTIVATED 26
AUX **26**
MENU STRUCTURE **27**
SET POWER 28
SET TEMPERATURE 28
SET ADJUSTMENTS **28**
BURN POT CLEANING 28
STAND - BY 28
ENABLE CHRONO 29
PELLET ADJUSTMENT 29
USER MENU **29**
SET CLOCK 29
CHRONO 30
ADJUSTING LANGUAGE 31
DISPLAY 31
RESET 32
OTHER FUNCTIONS **32**
AIR DISCHARGE 32
FIRST LOAD 32
MAINTENANCE **33**
DAILY CLEANING TO BE CARRIED OUT BY THE USER **33**
DISPLAYS **37**
ALARMS **38**

WARNINGS

This instructions manual is an integral part of the product: make sure that it always accompanies the appliance, even if transferred to another owner or user, or if transferred to another place. If it is damaged or lost, request another copy from the area technician. This product is intended for the use for which it has been expressly designed. The manufacturer is exempt from any liability, contractual and extracontractual, for injury/damage caused to persons/animals and objects, due to installation, adjustment and maintenance errors and improper use.

Installation must be performed by qualified staff, which assumes complete responsibility for the definitive installation and consequent good functioning of the product installed. One must also bear in mind all laws and national, regional, provincial and town council Standards present in the country in which the appliance has been installed, as well as the instructions contained in this manual.
The Manufacturer cannot be held responsible for the failure to comply with such precautions.

After removing the packaging, ensure that the content is intact and complete. Otherwise, contact the dealer where the appliance was purchased.
All electric components that make up the product must be replaced with original spare parts exclusively by an authorised after-sales centre, thus guaranteeing correct functioning.

SAFETY

- The generator must not be used by persons (including children) with reduced physical, sensory and mental capacities or who are unskilled persons, unless they are supervised and trained regarding use of the appliance by a person responsible for their safety.
- Children must be checked to ensure that they do not play with the appliance.
- Do not touch the generator when you are barefoot or when parts of the body are wet or damp.
- The safety and adjustment devices must not be modified without the authorisation or indications of the manufacturer.
- Do not pull, disconnect, twist electric cables leaving the stove, even if disconnected from the electric power supply mains.
- It is advised to position the power supply cable so that it does not come into contact with hot parts of the appliance.
- The power supply plug must be accessible after installation.
- Do not close or reduce the dimensions of the airing vents in the place of installation. The airing vents are essential for correct combustion.
- Do not leave the packaging elements within reach of children or unassisted disabled persons.
- The hearth door must always be closed during normal functioning of the product.
- When the appliance is functioning and hot to the touch, especially all external surfaces, attention must be paid
- Check for the presence of any obstructions before switching the appliance on following a prolonged period of inactivity.
- The generator has been designed to function in any climatic condition (even critical). In particularly adverse conditions (strong wind, freezing) safety systems may intervene that switch the generator off. If this occurs, contact the technical after-sales service and always disable the safety systems.
- In the event the flue catches fire, use suitable systems for suffocating the flames or request help from the fire brigade.
- This appliance must not be used to burn waste
- Do not use any flammable liquids for ignition
- During the filling phase do not put the bag of pellets to into contact with the product
- The majolicas are top quality artisan products and as such can have micro-dots, crackles and chromatic imperfections. These features highlight their valuable nature. Due to their different dilation coefficient, they produce crackling, which demonstrate their effective authenticity. To clean the majolicas, it is recommended to use a soft, dry cloth. If a detergent or liquid is used, the latter could penetrate inside the crackles, highlighting them.

ROUTINE MAINTENANCE

Based on Decree 22 January 2008 n°37 art.2, routine maintenance means interventions aimed at reducing degradation due to normal use, as well as dealing with accidental events entailing the need of first interventions, which however do not modify the structure of the system upon which one is intervening or its intended use according to the requirements laid down by the technical standards in force and by the manufacturer's use and maintenance manual.

HYDRAULIC SYSTEM

Certain concepts referring to the Italian UNI 10412-2 (2009) Standard are described in this chapter.
As previously described, when installing, all national, regional, provincial and town council Standards in force provided by the country in which the appliance has been installed must be complied with.

TABLE OF DEVICES FOR CLOSED VESSEL SYSTEM, PRESENT AND NOT PRESENT IN THE PRODUCT	
Safety valve	☑
Pump control thermostat (managed by the water probe and board program)	☑
Acoustic alarm activation thermostat	-
Water temperature indicator (display)	☑
Pressure transducer with display	☑
Acoustic alarm	-
Automatic circuit breater switch (managed by board program)	☑
Pressure transducer with minimum and maximum pressure switch alarm	☑
Water overheating automatic circuit breaker (blocking thermostat)	☑
Circulation system (pump)	☑
Expansion system	☑

During installation of the stove it is MANDATORY to adjust the system with a manometer in order to display the water pressure.

INSTALLATION AND SAFETY DEVICES

The installation, relative system connections, commissioning and inspection of correct functioning must be carried out perfectly, in total compliance with Standards in force, both national, regional and municipal, as well as these instructions.
For Italy, installation must be carried out by professionally authorised staff (Ministerial Decree dated 22.01.08 n°37).
The manufacturer declines all responsibility for damages to objects and/or persons caused by the system.

SAFETY DEVICES FOR CLOSED VESSEL SYSTEM

According to the UNI 10412-2 (2009) Standard in force in Italy, the closed systems must have: safety valve, pump control thermostat, acoustic alarm activation thermostat, temperature indicator, pressure indicator, acoustic alarm, regulation automatic circuit breaker switch, automatic circuit breaker block switch (block thermostat), circulation system, expansion system, safety dissipation system incorporated with the generator with thermal safety valve (self-activated), whenever the appliance does not have a temperature self-adjustment system.

DISTANCES OF SAFETY DEVICES ACCORDING TO THE STANDARD

The temperature safety sensors must be in place on the machine at a distance no greater than 30 cm from the flow connection.

Whenever the generators lack a device, those missing can be installed on the generator flow pipe, within a distance no greater than 1m from the machine.

COMPONENT	DISTANCE
Temperature safety sensors	On the machine or not exceeding 30 cm
Missing devices because not as per standard	Not exceeding one metre, on the flow pipe

The domestic heating appliances with automatic feeding must: be equipped with a fuel block thermostat or with a cooling circuit set up by the appliance manufacturer.
The cooling circuit must be activated by a thermal safety valve, in order to ensure that the limit temperature set forth by the Standard is not exceeded.
Connection between the power supply unit and the valve must be free from interceptions.
The pressure upstream from the cooling circuit must be at least 1.5 bar.

TYPE OF SYSTEM

There are two different types of system:
- Open vessel plant and closed vessel plant.

The product has been designed and realised to work with closed vessel systems.

CLOSED VESSEL PLANT

System in which the water it contains is not in direct or indirect communication with the atmosphere. Generally, the closed vessel system has one of the following expansion vessels:
- Pre-loaded closed expansion vessel with membrane impermeable to the passage of gases.
- Automatic closed expansion system with compressor and membrane impermeable to the passage of gases.
- Automatic closed expansion system with transfer pump and membrane impermeable to the passage of gases.
- Expansion system without diaphragm.

GENERALITY

The closed systems must have:
- Safety valve
- Pump control thermostat
- Acoustic alarm activation thermostat
- Temperature indicator
- Pressure indicator
- Acoustic alarm
- Adjustment automatic circuit breaker switch
- Automatic circuit breaker switch (block thermostat)
- Circulation system
- Expansion system
- Safety dissipation system incorporated with the generator with thermal safety valve (self-activated), whenever the appliance does not have a temperature self-adjustment system

SAFETY VALVES

The load capacity of the safety valve must allow the discharge of a quantity of vapour, not lower than: Q / 0.58 [kg/h] where: Q is the useful outlet power to the generator water expressed in kilowatt. The diameter of the minimum net transversal section of the valve inlet must not be lower than 15 mm. The valve load pressure, equal to the calibration pressure, increased by the overpressure, cannot exceed the maximum exercise pressure of the heat generator. The designer must check that the maximum pressure existing in every point of the system, does not exceed the maximum exercise pressure of its every component . The safety valve must be connected to the upper part of the heat generator or outlet pipes, very close to the generator. The length of the piping between the generator coupling and the safety valve must not exceed 1 m. The piping connecting the safety valve to the heat generator must not be interrupted and must not have, in any point, a cross-section lower than than that of the safety

valve inlet or than the sum of the inlet cross-sections, in the event of several valves serving a single pipe. The discharge piping of the safety valve must be realised in order not to prevent the regular functioning of the valves and not to cause damages to persons; the discharge must flow immediately near the safety valve and be accessible and visible. The diameter of the discharge piping must not however be lower than that of the outlet connection of the safety valve. For diameter of outlet connection it is intended the minimum internal diameter on the valve outlet upstream of the eventual internal threading.

CLOSED EXPANSION VESSEL

Warnings: check that the preload of the expansion vessel is set to 1.5 bar.
The vessel maximum exercise pressure must not be lower than the calibration pressure of the safety valve, increased by overpressures, characteristic of the same valve, bearing in mind the eventual level difference between vessel and valve and the pressure generated by the functioning of the pump. The capacity of the expansion vessel/s is evaluated depending on the total system capacity as results from the project. The closed expansion vessels must comply with the provisions concerning the design, manufacturing, conformity assessment and use of pressure appliances. Intercepting objects or section decreases must be inserted/practiced on the connection piping, which can be constituted by system portions. The insertion of a three-way intercepting valve which allows connection between the vessel and the atmosphere for maintenance Operations, is allowed. Such device must be protected against accidental manoeuvres. The connection pipe must be realised in order not to present scales or deposits storage points. In case of more heat generators which feed the same plant or the same secondary circuit, each heat generator must be connected directly to the expansion vessel or plant expansion vessels unit, altogether dimensioned for the total volume of water contained in the same plant or the same independent circuit. Where it is necessary to separate the individual heat generator from the expansion vessel or expansion vessels unit, a three-way tap must be applied on the connection piping between the generator and the vessel, in order to ensure, in every position, the connection of the generator with the expansion vessel or with the atmosphere. The expansion vessels, the connecting pipes, the bleed pipes and drain pipes must be protected from freezing, where this phenomenon occurs. The solution used for this purpose is described in the design.

COMMISSIONING CHECKS

Before connecting the boiler:
a) wash all system piping in order to remove any residues which might compromise the correct functioning of certain system components (pumps, valves, etc.).
b) check to verify that the flue has adequate draft, is not narrowed and that other appliances do not discharge into the flue.
This is to prevent unexpected power increases. Only after this control can the flue fitting be mounted between the boiler and the flue. A check of the connections with pre-existing flues is recommended.

AUTOMATIC THERMOSTATIC MIXER VALVE (MANDATORY)

It is required to create an adequate anti-condensation circuit that ensures a return temperature for the appliance of at least 55° C. The anti-condensation valve, for example, is applied in solid fuel boilers as it prevents the return of cold water in the heat exchanger.

Routes 1 and 3 are always open and, together with the pump installed on the return, they guarantee water circulation inside the biomass boiler exchanger.

A high return temperature allows efficiency improvement, reduces formation of smoke condensation and prolongs the life span of the generator.

Valves on the market have different calibrations. The manufacturer advises use of model 55°c with 1" hydraulic connections.
Once the valve calibration temperature is reached,
route 2 is opened and the boiler water goes to the system via the flow.

Valve sold as an accessory (optional)

LILIANA IDRO - DIADEMA IDRO BASIC HYDRAULIC SYSTEM DIAGRAM



KEY		
A	Combustion air inlet	Ø 60mm
B	Smoke exhaust outlet	Ø 120mm
T1	3 bar safety valve	1/2 "
T2	Boiler flow/output	1"
T3	Boiler return/inlet	1"
M	Pressure Gauge	
T	Thermometer	
G	Filling system	
S	Safety valve discharge	
SI	System exhaust	
VB	Balance valve	
VMTA	Thermostatic mixer valve 55°C	
VMS	Domestic hot water mixing valve	

IT IS RECOMMENDED TO CONSULT THE TEMPLATES MANUAL AT FOR FURTHER INFORMATION RELATIVE TO THE HYDRAULIC CONNECTIONS, AIR INTAKE/FLUE EXHAUST AND DIMENSION SPECIFICATIONS OF THE PRODUCT IN QUESTION.

STOVE POSITIONING

For correct product functioning, it is recommended to position it so that it is perfectly level, using a spirit level.

REARMS

The figures below illustrate the positions of the tank (85°C) and H2O (100°C) rearms. Contact the qualified technician if one of the rearms should be triggered, so as to verify the cause.



FEATURES

	DIADEMA IDRO LILIANA IDRO
Water content of the thermo-product heat exchanger (l)	21
Volume of expansion vessel integrated in the thermo-product (l)	8*
3 bar safety valve integrated in the thermo-product	SI
Minimum and maximum pressure switch integrated into the thermo-product	SI
Pump integrated into the thermo-product	SI
Pump max. head (m)	5

*** ENVISION A POSSIBLE ADDITIONAL EXPANSION VESSEL DEPENDING ON THE SYSTEM WATER CONTENT.**

The diagram to the side illustrates the behaviour of the pump used on our thermo-products at the speeds that can be set.



DEVICES

(in the relevant models)

Door micro switch: With the door open, the operation of the burn pot cleaning system is blocked
Electronic pressure switch: in the event of inadequate pression, it sends the machine in alarm conditions
F 2.5 A 250 V fuse (stoves): protects the machine from violent current surges
85°C calibrated mechanical bulb with manual rearm: intervenes by blocking fuel feed if the pellet tank t° reaches the limit of 85°C. **Rearm must be performed by qualified staff and/ or the manufacturer's technical after-sales assistance.**
Pellet tank temperature control probe: if the tank over-heats, the machine automatically modulates to return to normal temperature values
Mechanical air pressure switch: blocks the pellet in the event of insufficient depression

REFERENCE STANDARDS

The installation must be in compliance with:

- **UNI 10683 (2012) heat generators fed with wood and other solid fuels: installation.**

The chimneys must be in compliance with:

- UNI EN 13063-1 and UNI EN 13063-2, UNI EN 1457, UNI EN 1806 in the event of non-metallic chimneys:
- EN 13384-1 (13384) chimneys. Thermal and fluid dynamic calculation methods.
- UNI EN 1443 (2005) chimneys: general requirements.
- UNI EN 1457 (2012) chimneys: clay/ceramic flue liners.
- UNI/TS 11278 (2008) Metal - chimneys/flue liners/flue ducts.
- UNI 7129 point 4.3.3 Fire Brigade provisions, local rules and regulations.

NATIONAL, REGIONAL, PROVINCIAL AND TOWN COUNCIL REGULATIONS

One must also bear in mind all laws and national, regional, provincial and town council Standards present in the country in which the appliance has been installed.

TERMS AND DEFINITIONS

Aeration: Air renewal is required both for the disposal of the combustion products, and to prevent mixtures with a hazardous content of non-combusted gases.

Closed hearth appliance: Appliance designed for operation with closed combustion chamber.

Forced draught appliance: Appliance with ventilation in the fumes circuit and combustion with fumes flow at a positive pressure with respect to the environment.

Chimney: Structure consisting in one or several walls containing one or several outflow airways.
The purpose of this predominantly vertical element is to expel the combustion products at a convenient height from the ground.

Smoke duct: Component or components that connect the outlet of the heat generator to the chimney.

Chimney cap: Device that placed on the chimney outlet allows the dispersion of the combustion products even in presence of adverse weather conditions.

Condensation: Liquid products which form when the fumes temperature is lower or equal to the water dew point.

Ducting pipe: Pipe made up of one or several predominantly vertical elements, specifically suitable for collecting and expelling the fumes, as well as to withstand the relative components and any condensate over time,
suitable to be installed in a chimney, existing or new technical compartment, even in new buildings.

Sealed installation: Installation of an appliance with sealed operation, so that all the air required for combustion is taken from outside.

Maintenance: Set of procedures required to ensure and maintain safety and functionality over time and maintain the efficiency of the system within the prescribed parameters.

Chimney system: Chimney installed using a combination of compatible components, manufactured or specified by a sole manufacturer whose product liability covers the entire chimney.

Fumes exhaust system: Flue gas exhaust system, independent from the appliance made up of a smoke duct, chimney or individual flue and chimney cap.

Radiation area: Area immediately in front of the hearth in which the radiant heat caused by combustion is diffused.

Reflux area: Area beyond the extrados of the roof in which overpressure or depressions occur, which may affect the proper discharge of the combustion products.

FUNCTIONAL OPERATIONS DIAGRAM

State of the art installation and proper system operation include a series of activities:

1. Preliminary activities:

- Verification of the suitability of the power of the heat generator based on the characteristics of the system
- verification of the suitability of the installation site,
- verification of the suitability of the fumes exhaust system,
- verification of the suitability of the outside air inlets;

2. Installation:

- implementation of ventilation and connection to the outer air inlets,
- implementation and connection to the fumes exhaust system,
- assembly and installation,
- electric and hydraulic connections,
- installation of insulation,
- ignition and operation test,
- installation of finishings and coverings;

3. Issue of complementary documentation;

4. Inspection and maintenance.

Other actions may be required in relation to specific requests of the competent authority.

PRELIMINARY ACTIVITIES

GENERAL

Verification of compatibility of the system, of any restrictions required by local administrative regulations, special or conventional requirements resulting from condominium regulations, constraints, laws or administration deeds must precede any other assembly or installation operation.

One must especially verify the suitability:

- of the installation premises, of the appliances already installed in the installation premises and in the adjacent and adjoining premises, also powered by different fuels, with particular reference to non-compliant installations.

- of the fumes exhaust system
- of the outside air inlets

SUITABILITY OF THE FUMES EXHAUST SYSTEM

Installation must be preceded by a compatibility test between the appliance and the fumes exhaust system, by verifying:

- the existence of documentation relating to the system;
- existence and content of the chimney plaque;
- suitability of the internal section of the chimney;
- absence of obstructions all along the chimney;
- predominantly vertical height and development of the chimney;
- existence and suitability of the chimney cap;
- distance of the outside wall of the chimney and of the smoke duct from
- combustible materials;
- chimney type and material;
- absence of other chimney connections.

INSTALLATION

Installation in premises with fire hazards is forbidden. Installation in residential premises (except for sealed operation appliances) is also forbidden:

- in which there are liquid fuel-operated appliances with continuous or intermittent operation, which draw the combustion air in the room in which they are installed, or

- in which there are type B gas appliances intended for room heating, with or without production of domestic hot water and in adjacent and adjoining premises, or

- in which, in any case, the depression measured during installation between the internal and external environment is greater than 4 Pa

Installations in bathrooms, bedrooms and studio flats

Installation in bathrooms, bedrooms and studio flats is only allowed for sealed or closed hearth appliances with ducted combustion air taken from the outside.

Installation premises requirements

The support surfaces and/or points must have a suitable load-bearing capacity to support the weight of the appliance, of the accessories and coatings.
The adjacent, side and rear walls and the supporting surface must be made of non-combustible material. Installation near combustible materials or those sensitive to heat is permitted as long as there is a suitable safety distance, which for pellet stoves is equal to:

REFERENCES	INFLAMMABLE OBJECTS	NON-INFLAMMABLE OBJECTS
A	200 mm	100 mm
B	1500 mm	750 mm
C	200 mm	100 mm



figure 1



figure 2

In any case the temperature of the adjacent combustible materials must not reach a temperature equal to or greater than the room temperature increased by 65°C.

The minimum volume of the premises in which to install the appliance must be greater than 15 m^3.

VENTILATION AND AERATION OF THE INSTALLATION PREMISES

Ventilation is deemed sufficient when the room is equipped with air inlets according to the table:
Air inlet
See figure 2

Appliance categories	Reference standard	Percentage of the net opening section with respect to the appliance fumes outlet section	Minimum net opening value of the ventilation duct
Pellet stoves	UNI EN 14785	-	80 cm^2
Boilers	UNI EN 303-5	50%	100 cm^2

In any case ventilation is deemed sufficient when the pressure difference between the external and internal environment is equal to or less than 4 Pa.
In the presence of type B gas appliances with intermittent operation not intended for heating, they must have their own aeration and/or ventilation opening. The air inlets must meet the following requirements:

- they must be protected with grids, metal mesh, etc., but without reducing the net useful section;
- they must be made so as to make the maintenance operations possible;
- positioned so that they cannot be obstructed;

The flow of clean, uncontaminated air can also be obtained from a room adjacent to that of installation (indirect aeration and ventilation), as long as the flow takes place freely through permanent openings communicating with the outside.
The adjacent room cannot be used as a garage, warehouse of combustible material or for any other activity with a fire hazard, bathroom, bedroom or common room of the building.

FUMES EXHAUST SYSTEM

GENERAL REQUIREMENTS

The heat generator works in a vacuum and has an output fan for fume extraction. Each appliance must be connected to a suitable fumes exhaust system and ensure adequate dispersion of the combustion products into the atmosphere. The combustion products must discharged above the roof. Direct discharge from the wall or towards closed spaces is forbidden, even with clear skies.
In particular, it is forbidden to use flexible and extendible metal pipes.
The chimney should only receive the exhaust of the smoke duct connected to the appliance; collective flues or conveying exhausts from hoods above cooking appliances of any kind, or exhausts from other generators into the chimney itself or smoke duct are not allowed.
The smoke duct and the chimney must be connected with a continuity solution, in order to prevent the chimney from resting on the appliance.
It is forbidden to have other air supply channels and pipes for plant engineering transit inside the fumes exhaust systems, especially if over-sized.

The components of the fumes exhaust system must be chosen in relation to the type
of appliance to be installed in compliance with:

- in the event of metal chimneys, UNI/ TS 11278, with particular attention to what is stated in the specification;
- in the event of non-metallic chimneys: UNI EN 13063-1 and UNI EN 13063-2, UNI EN 1457, .-UNI EN 1806; considering especially:
- temperature class;
- pressure class (fumes seal) at least equal to the seal required for the appliance;
- moisture resistance (resistance to condensation);
- class or level of corrosion and specification of the materials constituting the inner wall in contact with the fumes.
- soot fire resistance class;
- minimum distance from combustible materials
- Where due to high efficiency a pellet stove has fumes at a temperature of less than 160°C + ambient (see technical data) it must be resistant to moisture.

The installer of the fumes exhaust system, once the installation is complete and the relevant checks and inspections have been made, must fix the chimney plaque supplied by the manufacturer with the product in a visible manner, near the fireplace, and which must be completed with the following information:

- nominal diameter;
- distance from combustible materials, indicated in millimetres, followed by the arrow and flame symbol;
- installer data and date of installation.

Every time one must cross combustible materials, the following indications must be complied with:



SYMBOL	DESCRIPTION	QUOTA[MM]
b	Minimum distance of combustible materials from the intrados of the framework/floor/wall	500
b.1	Minimum distance of combustible materials from the extrados of the framework/floor	500
a	Minimum distance from combustible materials defined by the manufacturer	G(xxx)
The single wall pipes are indicated in white. The insulated double wall chimney systems are indicated in grey.		
One can disregard the quota only in the event of using an appropriate heat protection screen (for example: wall plate) to protect the intrados of the framework/floor		

SMOKE DUCT

General requirements
The smoke ducts must be installed in compliance with the following general requirements:

- be equipped with at least one sealed outlet for eventual fumes sampling;
- they must be insulated if they cross through rooms that are not to be heated or outside the building;
- they must not cross rooms in which the installation of combustion appliances is forbidden, nor in other premises compartmentalised against fire or with a fire hazard, nor in rooms and/or areas that cannot be inspected;
- they must be installed so as to allow normal thermal expansion;
- they must be fitted to the opening of the chimney without protruding inwards;
- the use of flexible metal pipes to connect the appliance to the chimney is not allowed;



- counter-slope sections are not allowed;
- the smoke ducts must have, along their entire length, a diameter that is no less than that of the attachment of the appliance exhaust pipe; any section changes are allowed only on the inlet to the chimney;
- they must be installed so as to limit the formation of condensation and prevent their release from the joints;
- they must be positioned at a distance no less than that indicated in the product specifications from combustible materials;
- the smoke channel/duct must allow to collect the soot and to be cleaned using a swab and inspected after being disassembled, or through inspection openings when not accessible from inside the appliance.

ADDITIONAL REQUIREMENTS FOR APPLIANCES FITTED WITH AN ELECTRIC FAN FOR FUMES EXPULSION

For the heat generator appliances equipped with electric fan for expelling fumes, the instructions below must be followed:

- The horizontal sections must have a minimum upward slope of 3%
- The length of the horizontal section must be minimal and, in any case, no longer than 3 metres
- The number of direction changes including the one due to the use of the "T" element must not be more than 4.

EXAMPLES OF CORRECT CONNECTION TO THE CHIMNEY

Installation with internal flue



Installation with internal - external flue



IT IS NOT RECOMMENDED TO INSTALL A 90° BEND AS THE FIRST INITIAL PART, SINCE THE ASH WOULD BLOCK THE PASSAGE OF THE FUMES IN A SHORT TIME, CAUSING PROBLEMS TO THE GENERATOR DRAUGHT.:





EXAMPLES OF CORRECT CONNECTION TO THE CHIMNEY


Protection from rain and wind
Steel plate, airtight
"T" fitting with inspection plug
Protection from rain and wind
Max 3 mt
3 - 5%
"T" fitting with inspection plug
Insulated "T" fitting with inspection plug

It is mandatory to use airtight pipes.

CHIMNEY

In addition to the general requirements, the chimneys for releasing combustion products into the atmosphere must:

- operate under negative pressure (operation under positive pressure is not allowed);
- have a preferably circular internal section; square or rectangular sections must have rounded corners with a radius of no less than 20 mm (hydraulically equivalent sections may be used, as long as the ratio between the longer side and the shorter side of the rectangle, which circumscribes the section, is in any case no greater than 1.5);
- be designed for fumes be designed for fumes expulsion;
- be predominantly vertical and have no narrowing along their entire length;
- have no more than two direction changes with a slope angle no greater than 45°;
- be fitted with, in the event of operating in damp conditions, a device for reflux drainage (condensation, rainwater);

Ducted system

A ducted system can be installed with one or more ducts, operating only with negative pressure with respect to the environment.

The flexible hose compliant with UNI EN 1856-2, with T400-G characteristics, meets the requirements.

CHIMNEY CAPS

The chimney caps must meet the following requirements:

- they must have a useful outlet section no less than double of that of the chimney/ducted system on which it is installed;
- they must be adapted in order to prevent the penetration of rain and snow in the chimney/ducted system;
- they must be built so that, in the event of winds coming from all directions and from any angle, the expulsion of combustion products is in any case ensured;
- they must be free from mechanical intake aids.

COMBUSTION PRODUCTS OUTLET QUOTA

The outlet quota is determined by measuring the minimum height between the roof covering and the lower point of the fumes expulsion section into the atmosphere; this quota must be outside the reflux area and at an adequate distance from obstacles which hinder or make the expulsion of the combustion products difficult or from openings or accessible areas.

Reflux area
The outlet quota must be outside the reflux area calculated according to the indications below.
Near the ridge one considers the lowest between the two.

Buffer area for outlet quota



Clear area for outlet quota above the roof slope (β >10°)

REFERENCE	DESCRIPTION	CLEAR AREA (MM)
c	Distance measured at 90° from the roof surface	1300
a	Height above the ridge of the roof	500

The outlet of a chimney/ducted system must not be near obstacles that may create turbulence areas and/or prevent proper expulsion of combustion products and maintenance operations to be carried out on the roof.
Verify the presence of other chimney caps or skylights and dormers.

FUMES EXHAUST SYSTEM PRODUCT REQUIREMENTS

Temperature class

In the event of a pellet appliance, temperature classes below T200 are not allowed.

Soot fire resistance class

The fumes exhaust system interlocked with appliances supplied by solid fuels require soot fire resistance, and the specification must be indicated by the letter G followed by the distance from combustible materials in millimeters (XX) (in compliance with UNI EN 1443) .

In the event of pellet appliances, the fumes exhaust systems must be airtight; if double designation elements are used (G and O, with or without seal elastomer) for connecting the appliance to the chimney, one must comply with the minimum distance XX in millimeters, indicated for designation G; in the event of fire due to soot, one must ensure the restoration of the initial conditions (by replacing the gaskets and damaged items and cleaning those remaining in use).

Ignition tests

Operation of the appliance must be verified with an ignition test, i.e.:

- for mechanical feed appliances, one must complete the ignition test, verify proper operation for at least the next 15 minutes and adjust the switch-off;

For appliances installed in a hot water heating system (closed fireplaces, thermo-stoves), testing must also extend to the entire hydraulic circuit.

Coverings and finishings

The coverings and finishings must only be applied after having verified the proper operation of the appliance according to the indicated modalities

TECHNICAL INSTALLATION DOCUMENTATION

When installation is complete, the installer must provide the owner or person acting for him, according to the legislation in force, with the declaration of conformity, supplied with:

1) the use and maintenance manual of the appliance and of the system components (such as for example, the smoke ducts, chimney, etc.);
2) photocopy or photograph of the chimney plaque;
3) system booklet (where applicable).

The installer must ask to be issued with a receipt stating that the documentation has been provided, and must keep it with a copy of the technical documentation relating to the installation.

Installation performed by several parties

If the individual installation steps are carried out by different parties, each must document the work carried out for the customer and the for the operator working on the next step.

INSPECTION AND MAINTENANCE

Frequency of operations
Maintenance of the heating system and of the appliance must be carried out on a regular basis according to the table below:

TYPE OF APPLIANCE INSTALLED	<15kW	(15- 35) kW
Pellet operated appliance	1 year	1 year
Water operated appliances (closed fireplaces, thermo-stoves, thermo-kitchens)	1 year	1 year
Boilers	1 year	1 year
Fumes exhaust system	4 t of fuel used	4 t of fuel used

For further details refer to the "cleaning and maintenance" chapter.

Inspection and maintenance report

At the end of the inspection and/or maintenance operations, a report must be issued and released to the owner, or person acting for him, who must confirm its receipt in writing. The report must indicate the situations encountered, the action taken, any components replaced or installed and any comments, recommendations and requirements.
The report must be kept with the relative documentation.

In the inspection and maintenance report one must mention:

- anomalies detected that cannot be removed, which pose a risk to the safety of the user or serious damage to building;
- components that have been tampered with.

If anomalies as per above were detected, the owner, or person acting for him, must be warned in writing, in the maintenance report, to refrain from using the system until the safety conditions have been fully restored.

The inspection and maintenance report must include the main information of the technician or company who performed the inspection and/or maintenance operations, with their contact details, date of intervention and the signature of the operator.

PELLETS AND FEEDING

Pellets are made by applying high pressure to sawdust, or wood waste products (not containing paint) from sawmills, carpentry and other activities related to processing and working with wood. Given that it does not use any glue to hold it together this type of fuel is completely environmentally friendly. In fact the compactness of the pellets over time is guaranteed by a natural substance found in the wood itself: wood coal. In addition to being an environmentally friendly fuel in that it pushes wood residues to the limits pellets also have technical advantages. While wood has a calorific value of 4.4kWh/kg. (with 15% humidity after around 18 months of seasoning) the calorific value of pellets is 5 kWh/kg. Pellet density is 650kg/m3 and the water content is equal to 8% of its weight. For this reason they do not require seasoning in order to arrive at a sufficiently adequate degree of heat yield.

The pellets used must comply with the characteristics described by the following standards:

- **EN PLUS - UNI EN 16961 - 2 class A1 or A2**
- **Ö-NORM M 7135**
- **DIN PLUS 51731**

The manufacturer always recommended using pellets with a diameter of 6 mm with its products.



PELLET STORAGE

In order to ensure problem-free combustion pellets must be stored in a dry place.
Open the tank lid and load the pellets using a scoop.

THE USE OF EXPIRED PELLETS OR ANY OTHER MATERIAL WILL AFFECT THE FUNCTIONALITY OF YOUR GENERATOR AND MAY LEAD TO THE TERMINATION OF THE WARRANTY AND CESSATION OF ANY ACCOMPANYING RESPONSIBILITY ON THE PART OF THE MANUFACTURER

CONTROL PANEL



DISPLAY ICONS KEY

	Indicates the receipt of the radio signal On = during radio communication Off = no radio communication Flashing = serial port excluded		Indicates the stove modulation On = the stove is working at the set power Flashing = the power at which the stove is working is different to the power set, the stove is modulating (for various reasons)
	Indicates the presence of an alarm. On: indicates the presence of an alarm Off: indicates the absence of alarms Flashing: indicates the deactivation of the depression sensor.		It indicates weekly programming functioning Indicator on = weekly programming active Indicator off = weekly programming disabled
	Indicates the water temperature status Off = the T° read by the probe is over the set temperature set On = the T° read by the probe is below the set temperature set		Indicates the contact of the external additional thermostat Closed contact = the contact of the external additional thermostat is closed. Open contact: the contact of the external additional thermostat is open. Flashing with contact closed: the contact of the external additional thermostat is closed and the STBY function is activated Flashing with contact open: the contact of the external additional thermostat is open and the STBY function is activated
	It indicates functioning of the fumes motor. Off = flue gas motor deactivated On = flue gas motor active Flashing = breakdown (contact technical after-sales service)		It indicates the summer/winter function (with an additional board) Off: Activates the winter function On: Activates the summer function
	Not used		It indicates the boiler request (with an additional board) Off = DHW satisfied, pump off Flashing : the puffer request exists but the work conditions are not satisfied, pump off On : the puffer is in request mode and the work conditions are satisfied, pump on
	It indicates functioning of the pellet feed motor Off = pellet feed motor deactivated On = pellet feed motor active		It indicates the heating request (with an additional board) Off : heating satisfied, pump off Flashing : the heating request exists but the work conditions are not satisfied, pump off On : the heating is in request mode and the work conditions are satisfied, pump on
	It indicates pump operation Off = pump deactivated On = pump active Flashing = the safety device is active (H2O temperature > 85°C)		It indicates the puffer request (with an additional board) Off : puffer satisfied, pump off Flashing : the puffer request exists but the work conditions are not satisfied, pump off On : the puffer is in request mode and the work conditions are satisfied, pump on

GENERAL MENU



BASIC INSTRUCTIONS

The following recommendations must be followed the first times the stove is ignited:

- Faint smells may be produced due to the drying of the paints and silicones used. Do not remain in the environment for long periods.
- Do not touch the surfaces as they could still be unstable.
- Air the room well several times.
- The hardening of the surfaces is terminated after several heating processes.
- This appliance must not be used to burn waste.

Before lighting the stove, the following points must be verified:

- The hydraulic system must be completed in compliance with the guidelines of the regulations and the manual.
- The tank must be full of pellets
- The combustion chamber must be clean
- The burn pot must be completely free and clean
- Check the hermetic closure of the fire door and the ash drawer
- Check that the power supply cable is connected correctly
- The bipolar switch in the rear right part must be positioned on 1.

Extraflame has an optional additional board that allows the boiler the following further functions when managing the system. The table below indicates the various possibilities that the optional can offer.	
DHW Storage Management	*
Puffer Management	*
3 heating areas	*
Instant DHW option	*
Puffer pump or 4th heating area management	*
Anti-legionella management for DHW storage	*
DHW storage chrono management	*
Auxiliary output management and control	*

THE REMOTE CONTROL

All that can normally be implemented through the LCD can be adjusted using the remote control.
The table below provides a detailed description of the various functions:

1	**ON / OFF**	Pressing the key for three seconds, the stove will switch-on or off
2	**POWER INCREASE**	Pressing the key will increase the operating power
3	**POWER DECREASE**	Pressing the key will decrease the operating power
4	**T° INCREASE**	The set temperature can be increased by pressing this key
5	**T° DECREASE**	The set temperature can be decreased by pressing this key
6	**ENABLE/DISABLE CHRONO**	Pressing the key once will enable or disable the chrono
7	**ENABLE DELAYED SWITCH-OFF**	The delayed switch-off can be set by pressing this key. For example, if the stove is set to switch-off in an hour, it shall switch-off automatically once the set time elapses, displaying the countdown every minute for delayed automatic shutdown.
8	**MENU**	This key allows to access the user and technical menu (the technical menu is reserved for assistance)
9	**INCREASE**	The set temperature can be increased by pressing this key
10	**ESC KEY**	The key allows the user to exit any program or display and returns to the main menu without saving the data
11	**BACK**	The key returns to the display of the various menus
12	**CONFIRMATION KEY**	This key confirms the adjustments made during the user menu programming phase
13	**FORWARD**	The key moves forward in the various menus
14	**ENABLE F1 FUNCTION**	Pre-set key for future applications
15	**DECREASE**	The key decreases the value to be set
16	**STOVE STATUS**	Pressing this key will display the general status of the stove

Important note: the numbers shown on the remote control are purely indicative and are not present on the remote control supplied with the product.

TYPE AND REPLACEMENT OF BATTERIES

The batteries are housed in the lower part of the remote control.
To replace them, remove the battery holder (as indicated in the figure at the back of the remote control), remove or insert the battery according to the symbol on the remote control and on the battery itself.



For operation, 1 CR2025, 3V lithium buffer battery is required.

The batteries used contain metals harmful for the environment. They must therefore be disposed of separately in appropriate containers.

IF THE REMOTE CONTROL IS OFF BECAUSE IT HAS NO BATTERIES, THE STOVE CAN BE CONTROLLED FROM THE CONTROL PANEL ON TOP OF IT.
WHILE REPLACING THE BATTERY, PAY ATTENTION TO THE POLARITY BY OBSERVING THE SYMBOL ON THE INSIDE COMPARTMENT OF THE REMOTE CONTROL.

COMMISSIONING SETTINGS

Once the power cable at the back of the stove has been connected, move the switch, also located on the back, to (I).
The switch at the back of the stove powers the stove board.
The stove remains off and a first screen appears on the panel reading OFF .

ADJUSTING TIME, DAY, MONTH AND YEAR

Set clock allows to adjust the time and date

CONTROLS PROCEDURE

- Press key 6 and **SET POWER** will appear
- Press key 2 several times until **USER MENU** is displayed
- Confirm using key 6
- **SET CLOCK** will appear.
- Confirm using key 6
- Use key 4 or 5 to select the day
- Proceed by pressing key 2
- Use the same procedure: 4 or 5 to set and key 2 to move forward; to adjust the hours, minutes, day, month and year
- Press key 1 several times to confirm and exit the menu

SET CLOCK	
DAY	MON, TUE, WED, ...SUN
HOURS	0...23
MINUTES	00...59
DATE	1...31
MONTH	1...12
YEAR	00...99

ADJUSTING THE LANGUAGE

It is possible to select the preferred language to display the various messages.

CONTROLS PROCEDURE

- Press key 6 and **SET POWER** will appear
- Press key 2 several times until **USER MENU** is displayed
- Confirm using key 6
- **SET CLOCK** will appear.
- Press key 2 until **SET LANGUAGE** appears
- Confirm using key 6
- Select the language using key 4 or 5.
- Press key 1 several times to confirm and exit the menu

SET LANGUAGE	
LANGUAGE	ITALIAN
	ENGLISH
	GERMAN
	FRENCH
	SPANISH

DO NOT USE ANY INFLAMMABLE LIQUIDS FOR IGNITION!
DO NOT ALLOW THE BAG OF PELLETS TO COME INTO CONTACT WITH THE BOILING HOT STOVE DURING THE FILLING PHASE!
IN THE EVENT OF CONTINUOUS NO IGNITION, CONTACT AN AUTHORISED TECHNICIAN.

IT IS FORBIDDEN TO USE THE APPLIANCE WITHOUT THE DIVIDER AND/OR GLASS PROTECTION (SEE THE FIGURE TO THE SIDE). ITS REMOVAL JEOPARDISES THE SAFETY OF THE PRODUCT AND IMMEDIATELY VOIDS THE WARRANTY PERIOD. IN THE CASE OF WEAR OR DETERIORATION REQUEST AFTER-SALES ASSISTANCE FOR REPLACEMENT OF THE PART (REPLACEMENT THAT IS NOT UNDER GUARANTEE AS THE COMPONENT IS SUBJECT TO WEAR).

BURN POT upper DIVIDER - KEEP THE CORRECT POSITION AS INDICATED IN THE FIGURE



OPERATION AND LOGIC



IGNITION
Once the "basic instructions" listed previously have been checked, press key 1 for three seconds to ignite the stove.
15 minutes are available for the ignition phase. After ignition and having reached the control temperature, the stove interrupts the ignition phase and passes to STARTING.

STARTING
During the start-up phase, the stove stabilises combustion, increasing it progressively, to then start ventilation and pass on to WORK.

WORK
During the work phase, the stove reaches the set power; see following item.

ADJUSTING POWER SETTING
Set the operating power (from 1 to 5) .
Power 1 = minimum level - Power 5 = maximum level.

H2O TEMPERATURE SET ADJUSTMENT
Set the boiler temperature between 65 - 80°C .

PUMP OPERATION
The pump activates water circulation when the t° of the water inside the stove reaches 60°C. As the pump always functions above 60°, an always open heating area is recommended to make product functioning homogenous, preventing overheating blocks. Normally this area is defined "Safety zone".

BURN POT CLEANING
At pre-set intervals the stove performs burn pot cleaning, switching the machine off.
When the cleaning phase is finished, the stove will re-start automatically and continue its work going back to the selected power level.

MODULATION and H-OFF
As the water temperature approaches the set point, the boiler starts to modulate automatically bringing itself to the minimum power.
If the temperature increases beyond the set point, it will automatically switch off indicating **H-OFF** and will automatically go back on when the temperature drops below the set point.

SWITCH-OFF
Press key 1 for three seconds.
When the operation has been performed, the appliance automatically enters the switch- off phase, blocking the supply of pellets.
The flue gas exhaust motor will remain on until the stove temperature has dropped below the factory parameters.

RE-IGNITION
The stove can only be re-ignited automatically or manually when the cooling cycle conditions and the preset timer have been satisfied.

ADDITIONAL ROOM THERMOSTAT

N.B. : Installation must be performed by an authorised technician

There is a possibility to thermostat a room adjacent to the room where the stove is positioned: just connect a thermostat following the procedure described in the next step (it is recommended to position the optional mechanical thermostat at a height of 1.50 m from the floor) . Stove functioning with the external thermostat connected in the STBY clamp can be different on the basis of the activation or deactivation of the STBY function.
The STBY clamp leaves the factory jumpered, therefore it is always with closed contact (on request).

ADDITIONAL THERMOSTAT FUNCTIONING WITH STBY ACTIVE

When the STBY function is activated, the -o/o- LED flashes. When the contact or external thermostat is satisfied (open contact / temperature reached), the stove will switch off. As soon as the contact or external thermostat switches to the "not satisfied" status (closed contact/temperature to be reached) it will re-ignite.
N.B.: stove operation depends on the temperature of the water inside the stove and relative factory setting restrictions. If the stove is in H OFF (water temperature reached), any additional contact or thermostat request will be ignored.

ADDITIONAL THERMOSTAT FUNCTIONING WITH STBY DEACTIVATED

When the STBY function is deactivated, the -o/o- LED is fixed.
When the contact or external thermostat is satisfied (open contact / temperature reached), the stove will go to minimum. As soon as the contact or external thermostat switches to the "not satisfied" status (closed contact / temperature to be reached) the stove will start to work again at the pre-set power.
N.B.: stove operation depends on the temperature of the water inside the stove and relative factory setting restrictions. If the stove is in H OFF (water temperature reached), any additional contact or thermostat request will be ignored.

ADDITIONAL THERMOSTAT INSTALLATION

- Switch the appliance off using the master switch positioned on the rear of the stove.
- Remove the plug from the socket.
- Refer to the electrical diagram to connect the two thermostat cables onto the relative clamps positioned on the rear of the machine, one is red and the other one is black (STBY clamp).

AUX

Connection reserved for Extraflame conveyed waves accessories.
Contact the dealer for further details



LILIANA IDRO - DIADEMA IDRO

MENU STRUCTURE



1 GO BACK - EXIT

2 3 PARAMETER SCROLLING: NEXT (2) ; PREVIOUS (3)

4 5 MODIFY SETTINGS DATA: INCREASE (4); DECREASE (5)

6 CONFIRM - ACCESS MENU

MENU		TEXT	VALUE	FUNCTION
SET POWER		POWER	01 - 05	Selecting the power
SET TEMPERATURE		SET H2O	65° - 80°C	Selection of the boiler temperature set-point
SET ADJUSTMENTS		BURN POT CLEANING	0..+50%	Burn pot automatic cleaning frequency adjustment
		STAND - BY	OFF - ON	Activation or deactivation of the stand-by function
		ENABLE CHRONO	OFF - ON	Activation/deactivation of the weekly programmer
		PELLETS	-30... +20%	Selecting the percentage of pellet feed
STATUS		STOVE STATUS	*References reserved to the technician*	
USER MENU	SET CLOCK	DAY	MON...SUN	Setting the day of the week
		HOURS	00...24	Adjustment of the hour
		MINUTES	00...59	Adjustment of the minutes
		DATE	1...31	Adjustment of the date
		MONTH	1...12	Adjustment of the month
		YEAR	00...99	Adjustment of the year
	SET CHRONO	ENABLE CHRONO	OFF	Activation/deactivation of the weekly programmer
		START - PRG1	OFF - 00:00	Time 1st ignition
		STOP - PRG1	OFF - 00:00	Time 1st switch-off
		MONDAY PRG1 OFF SUNDAY PRG1 OFF	ON / OFF	Ignition/switch-off consents for various days
		SET PRG1	65 - 80°C	Temperature setting for the 1st time span
		START - PRG2 00:10	OFF - 00:00	Time 2nd ignition
		STOP - PRG2 00:10	OFF - 00:00	Time 2nd switch-off
		MONDAY PRG2 OFF SUNDAY PRG2 OFF	ON / OFF	Ignition/switch-off consents for various days
		SET PRG2	65 - 80°C	Setting room temperature for the 2nd time slot
		START - PRG3 00:10	OFF - 00:00	Time 3rd ignition
		STOP - PRG3 00:10	OFF - 00:00	Time 3rd switch-off
		MONDAY PRG3 OFF ...SUNDAY PRG3 OFF	ON / OFF	Ignition/switch-off consents for various days
		SET PRG3	65 - 80°C	Setting room temperature for the 3rd time slot
		START - PRG4 00:10	OFF - 00:00	Time 4th ignition
		STOP - PRG4 00:10	OFF - 00:00	Time 4th switch-off
		MONDAY PRG4 OFF ...SUNDAY PRG4 OFF	ON / OFF	Ignition/switch-off consents for various days
		SET PRG4	65 - 80 °C	Setting room temperature for the 4th time slot
	LANGUAGE	ITAL - ENGL - DEUT - FRAN - ESPA		Selecting the language
	DISPLAY	KEY LOCK	ON - OFF	"Key lock function" activation / disabling
		BRIGHTNESS	OFF - 10...31	Selecting the display brightness
	RESET	RESET	ON / OFF	Resets the values modifiable by the user back to the default values.

SET POWER

The following menu allows to set the power. Minimum power 1, maximum power 5.

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Confirm using key 6
- The **POWER** will be displayed.
- Press 4 to increase the setting and 5 to decrease it.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status

SET TEMPERATURE

The following menu allows to set the boiler temperature. The possible settings are: 65 - 80°C.

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **SET TEMPERATURE** is displayed
- Confirm using key 6
- Press 4 to increase the setting and 5 to decrease it.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status

SET ADJUSTMENTS

BURN POT CLEANING

The menu allows to increase the frequency of the automatic burn pot cleaning.

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **SET ADJUSTMENTS** is displayed
- Confirm using key 6
- "**BURN POT CLEANING**" will appear.
- To increase the automatic cleaning frequency press 4.
- To go back to standard values (00) decrease by pressing 5
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status

STAND - BY

The Stby function is used if immediate stove switch-off or modulation via an additional thermostat is desired

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **SET ADJUSTMENTS** is displayed
- Press key 6.
- "**STAND BY**" will appear.
- Use keys 4 -5 to select enable "ON"/disable "OFF".
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.



ENABLE CHRONO

The boiler chrono can be enables/disables from this menu

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **SET ADJUSTMENTS** is displayed
- Press key 6
- Press key 2 until **ENABLE CHRONO** is displayed
- Use keys 4 -5 to enable **"ON"**/ disable **"OFF"**.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status



PELLET ADJUSTMENT

The following menu allows to adjust the percentage of pellet feed.
If the stove has functioning problems owing to the quantity of pellets, adjust pellet feeding directly from the control board.
The problems correlated to the amount of fuel can be divided into 2 categories:

NO FUEL:
- the stove can never develop a suitable flame, tending to remain very low even at high powers.
- at minimum power the stove tends to almost switch-off taking the stove into "**NO PELLETS**" alarm condition.
- when the stove displays the "**NO PELLETS**" alarm, there may be non-burned pellets inside the burn pot.

EXCESS FUEL:
- the stove develops a very high flame even at low power.
- the panoramic glass is very dirty, obscuring it almost totally.
- the burn pot tends to become encrusted, blocking the holes for air intake due to the excessive pellet feed, as it is only burned partially.

The adjustment to be performed is in percentage. Therefore a modification of this parameter will lead to a proportional variation of all stove feeding speeds.
Feeding is from -30% to +20%.

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **SET ADJUSTMENTS** is displayed
- Confirm using key 6
- Press key 2 until **PELLET** is displayed
- Press 4 to increase the load and 5 to decrease it
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status

USER MENU

SET CLOCK

- see chapter: commissioning settings

CHRONO

The chrono allows to program 4 time spans within a day to use every day of the week.
The switch-on and switch-off time can be set in every time slot, along with the days of use of the programmed time slot and the desired water temperature (65 - 80°C).



PROGRAMMING EXAMPLE

Let's suppose that the weekly programmer function is to be used and 4 time slots are to be used in the following way:

1st time slot: from 08:00 to 12:00 every day of the week, excluding Saturday and Sunday
2nd time slot: from 15:00 to 22:00 only on Saturday and Sunday, both times with a water temperature setting of 75°C

CONTROLS PROCEDURE:

Press key 6 once and **SET POWER** will appear

Press key 2 until **SET USER** appears

SET USER

1ST TIME SLOT SWITCH-OFF

Use keys 4 - 5 to enter the time "**12:00**", which corresponds to the switch-off time of the 1st time slot.

To confirm and continue programming, press button 6. Press button 3 to go back to the previous parameter

STOP PRG1 OFF
⋮
STOP PRG1 12:00

Press key 6 to confirm
SET CLOCK will appear.

Press key 2 until **SET CHRONO** appears

SET CHRONO

ENABLING THE 1ST TIME SLOT DAYS

To enable **ON**/ disable **OFF** the days use keys 4 and 5

Keys 2 and 3 to scroll the various days, select from Monday to Friday on **ON**, excluding Saturday and Sunday (**OFF**)
To confirm and proceed press key 6

MONDAY..PRG1 ON
⋮
FRIDAY..PRG1 ON

Press key 6 to confirm and continue programming.

START PRG1 OFF appears

START PRG1 OFF

1ST TIME SLOT H2O TEMPERATURE SETTING

Using buttons 4 - 5 select the desired **H2O** temperature.
(65-80°C)

To confirm and proceed press key 6

SET PRG1 75°C

1ST TIME SLOT SWITCH-ON

Use keys 4 - 5 to enter the time "**08:00**", which corresponds to the switch-on time of the 1st time slot

To confirm and continue programming, press button 6. Press button 3 to go back to the previous parameter

START PRG1 08:00

2ND TIME SLOT SWITCH-ON*
At this point, the second time slot must be programmed.

START PRG2 OFF

The sequence to be followed is the same and is repeated as for the 1ST TIME SLOT switch-on.

*2ND TIME SLOT SWITCH-ON

At this point, the second time slot must be programmed. The sequence to be followed is the same and is repeated as per the "1ST TIME SLOT SWITCH-ON". On this occasion it is only necessary to enter the time, for example start at 15:00 and Stop at 22:00 and to activate the days Saturday and Sunday by setting them at "ON".

RECOMMENDATIONS

The ignition and switch-off times must be within the arc of one day, from 0 to 24 and not over several days:
Before using the chrono function, set the current day and time. Therefore check that the points listed in the "Set clock" sub-chapter have been followed, so that the chrono function works. As well as programming it, activate it as well.

EXAMPLE

Switch-on time 07:00
Switch-off time 18:00 **CORRECT**

Switch-on time 22:00
Switch-off time 05:00 **INCORRECT**

TO ENABLE THE CHRONO FOLLOW THE INSTRUCTIONS AS DESCRIBED IN THE "ENABLE CHRONO" CHAPTER. WHEN THE WEEKLY PROGRAMMER IS ACTIVE, THE RELEVANT ICON WILL LIGHT UP ON THE CONTROL PANEL

ADJUSTING LANGUAGE

- see chapter: commissioning settings

DISPLAY

The "DISPLAY" menu contains two sub-menus:
- Key lock
- Brightness.

- KEY LOCK

The menu allows to lock the display keys (like mobile phone).

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **USER** is displayed.
- Confirm using key 6
- Press key 2 until "**DISPLAY**".
- Confirm using key 6
- **KEY LOCK** will appear - confirm with key 6
- Use keys 4 -5 to enable **"ON"**/ disable **"OFF"**.
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

USING THE KEY LOCK AFTER ACTIVATION:

TO LOCK THE KEYBOARD, PRESS KEYS 1 AND 5 AT THE SAME TIME UNTIL THE FOLLOWING APPEARS: "KEYS LOCKED"

TO UNLOCK THE KEYBOARD, PRESS KEYS 1 AND 5 AT THE SAME TIME UNTIL THE FOLLOWING APPEARS: "KEYS FREE"

- BRIGHTNESS

This menu allows to adjust the brightness of the display. The possible settings range from OFF - 10 to 31.
Activating OFF, the back light of the display will go off after a preset delay.
The back light will go on as soon as a key is pressed or if an alarm should be triggered in the machine.

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **USER** is displayed.
- Confirm using key 6
- Press key 2 until **DISPLAY** appears and confirm with key 6
- Press key 2 until **BRIGHTNESS** appears and confirm with key 6
- Press keys 4-5 to select the brightness
- Press key 6 to confirm and key 1 to return to the previous menus up to the initial status.

RESET

Allows to reset all values modifiable by the user to the default values. The data is:

CONTROLS PROCEDURE
- Press key 6 and **SET POWER** will appear.
- Press key 2 several times until **USER** is displayed.
- Confirm using key 6
- Press key 2 until "**RESET**" appears.
- Confirm using key 6
- Press keys 4-5 to select **ON** and press key 6.
- "**DONE**" will appear on the display to confirm

- SET H2O = 75°C
- SET POWER = 5
- ENABLE CHRONO = OFF
- START PRG1=OFF
- STOP PRG1 = OFF
- MONDAY PRG1 = OFF
- ...all chrono parameters OFF
- PELLET = 00%
- BURN POT CLEANING=00%
- STAND BY = OFF

OTHER FUNCTIONS

AIR DISCHARGE

This function allows to bleed any air in the stove. Once the function has been activated, the pump indicator light is activated on the display (for 15 minutes 30 seconds the pumps will be powered, alternating with 30 seconds of downtime).

To activate the function:
With the stove "OFF" press keys 1 and 4 at the same time, enter the password "77" using keys 4 and 5 and confirm with key 6.
Cut the power to interrupt.

FIRST LOAD

This function allows to activate the pellet feeding motor reducer for continuous functioning.
To activate the function:

When the stove is cold and "OFF" press keys 2 and 5 at the same time for a couple of seconds, the scrolling message “first load” will appear on the display.
To interrupt continuous loading simply press key 1.

MAINTENANCE

MAINTENANCE WARNINGS

Inspection and maintenance operations must be carried out by specialised technicians who are aware of the directions reported in this manual.
Before carrying out any work, make sure that:

- **The power cable's plug has been pulled out, as the generator might have been programmed to turn on.**
- **All the generator parts are cold.**
- **The ashes are completely cold.**
- **Periodically inspect the T-shaped fitting on the smoke pipe located on the outlet of the generator by removing the hermetic container, remove any ash and carefully place back the plug with the gasket.**

ATTENTION!
HAVE THE GENERATOR, VENTS AND SMOKE PIPE CLEANED AND CHECKED BY SPECIALISED PERSONNEL EVERY YEAR.

DAILY CLEANING TO BE CARRIED OUT BY THE USER

Daily cleaning must be carried out by the generator's user with the utmost care after reading the instructions related to the procedures that need to be carried out later described in this manual.

The images are for illustration purposes.

Burn pot:

Remove the burn pot from the relevant compartment and free the holes using the appropriate fire irons supplied, remove the ash from the burn pot using a suction device.
Suck the ash deposited in the brazier compartment.





Scrapers:

Cleaning of the heat exchangers allows to guarantee constant heat output through time. This type of maintenance must be performed at least once a day. To do this, just use the relevant scrapers positioned in the upper part of the stove, moving them up and down several times.



WEEKLY

Clean the combustion chamber and the ash drawer:

Empty the ash drawer every week or when required. It is recommended to remove the ash in the combustion chamber at least once a week using a suitable vacuum cleaner





MONTHLY

Cleaning the deflector:

The fumes deflector located in the upper part of the combustion chamber must be removed on a monthly basis.
(see figure to the side . To remove it simply pull out the central fumes deflector as if it were a drawer.



CLEAN CHECK UP ALARM 1 - 2

SHOULD THE ALARM "CLEAN CHECK UP" BE TRIGGERED, MAKE SURE THAT THE BOTTOM OF THE BURN POT IS FREE FROM RESIDUES OR SCALING. THE HOLES ON THE SIDE OF THE BURN POT (SEE FIGURE TO THE SIDE) MUST BE COMPLETELY CLEAR, TO ENSURE PROPER COMBUSTION. (SEE CHAPTER "CLEANING UNDER USER'S RESPONSIBILITY") ONE CAN USE THE "PELLET FEED ADJUSTMENT" FUNCTION TO ADJUST THE COMBUSTION ACCORDING TO THE DESCRIBED REQUIREMENTS. IF THE ALARM PERSISTS AND THE ABOVE LISTED CONDITIONS HAVE BEEN CHECKED, CONTACT THE QUALIFIED AFTER-SALES ASSISTANCE CENTRE.



ALWAYS FOLLOW THE INSTRUCTIONS IN MAXIMUM SAFETY CONDITIONS!

- **WITH THE STOVE FULLY COOLED DOWN, SWITCHED OFF AND DISCONNECTED FROM THE MAINS ELECTRICITY SO**
- **IF THE POWER SUPPLY CABLE IS DAMAGED, IT MUST BE REPLACED BY THE AFTER-SALES SERVICE OR BY A SIMILARLY QUALIFIED PERSON, SO AS TO AVOID ALL RISKS.**
- **FAILURE TO CLEAN JEOPARDISES SAFETY!**
- **FOR PROPER OPERATION, THE STOVE MUST UNDERGO ROUTINE MAINTENANCE BY A QUALIFIED TECHNICIAN, AT LEAST ONCE A YEAR.**

ROUTINE MAINTENANCE

Some images could be offset from the original model.





A	Fumes motor (disassembly and cleaning and fumes pipe and "T"), new silicone in the provided points	☑
B	Inspections of gaskets, ash drawer and door (replace them and apply silicone where envisioned)	☑
C	Combustion chamber and heat exchanger (full cleaning) including ignition-plug pipe	☑
D	Feed box (complete emptying and cleaning).	☑
E	*Room air fan disassembly and removal of dust and debris of any pellets	☑
F	Check air intake pipe and cleaning of the flow sensor	☑

ROUTINE MAINTENANCE

Some images could be offset from the original model.

A	Fumes motor (disassembly and cleaning and fumes pipe and "T"), new silicone in the provided points	☑
B	Inspections of gaskets, ash drawer and door (replace them and apply silicone where envisioned)	☑
C	Combustion chamber and heat exchanger (full cleaning) including ignition-plug pipe	☑
D	Feed box (complete emptying and cleaning).	☑
E	*Room air fan disassembly and removal of dust and debris of any pellets	☑
F	Check air intake pipe and cleaning of the flow sensor	☑





DISPLAYS	
DISPLAY	**REASON**
OFF	Stove off
START	The start-up phase is in progress
PELLET FEEDING	Continuous pellet feeding is in progress during the ignition phase
IGNITION	The ignition phase is in progress
START-UP	The start-up phase is in progress
WORK	The normal work phase is in progress
MODULATION	The stove is working at minimum
BURN POT CLEANING	Automatic burn pot cleaning is in progress
FINAL CLEANING	The final cleaning is in progress
STAND-BY	Stove off waiting for re-ignition due to an external thermostat The stove will only re-start when the external thermostat makes a request
STAND-BY COOLING	A new ignition is attempted when the stove has just been switched off. When the stove switches off, one must wait for the complete shutdown of the fumes motor, then clean the burn pot. The stove can only be re-ignited when these operations have been performed.
HOFF	Stove off due to water temperature over set As soon as the water temperature drops below the pre-set parameters, the stove will switch back on
T - OFF	Stove off waiting for re-ignition as all the requests have been satisfied
STAND-BY BLACK OUT	The stove is cooling after a power cut. Once cooling is completed it will re-start automatically
ANTI-FREEZE	The anti-freeze function is in progress as the H2O t° is below the factory set threshold the pump is active until the water reaches the pre-set factory parameter +2°C
ANTILOCK	The pump antilock function is in progress (only if the stove has been in an OFF state for at least 96 hours); the pump is activated for the time pre-set by the manufacturer, in order to prevent it from blocking
AUTO BLOW	The automatic blow is active

ALARMS		
DISPLAY	**EXPLANATION**	**SOLUTION**
	Indicates the presence of an alarm.	On: indicates the presence of an alarm Flashing: indicates the deactivation of the depression sensor. The alarm can be reset by pressing key 1 for 3 seconds only if the fumes motor has stopped and if 15 minutes have elapsed from when the alarm was displayed.
ASPIRATION FAULT	Fumes motor fault	Contact after-sales centre
FUMES PROBE	Fumes probe failure.	Contact after-sales centre
HOT FUMES	High flue gas temperature	Check pellet feed (see "Pellet feed adjustment"). If the problem cannot be solved, contact an authorised technician.
CLEAN CHECK UP 1 - 2 **(1 = IN START-UP STAGE)** **(2= IN OPERATING STAGE)**	The door is not closed correctly. The ash drawer is not closed correctly. The combustion chamber is dirty. The flue exhaust pipe is blocked.	Check hermetic door closure. Check hermetic closure of the ash drawer. Check cleanliness of the fumes pipe, of the sensor in the primary air channel and the combustion chamber.
NO IGNITION	The pellet feed-box is empty. Pellet feed calibration inadequate.	Check for the presence of pellets in the feed-box. Adjust pellet flow (see "Pellet feed adjustment"). Check the procedures described in the "Ignition" chapter.
NO IGNITION BLACK OUT	No current during the ignition phase.	Take the stove to OFF conditions using key 1 and repeat the procedure described in the "Ignition" chapter.
NO PELLETS	The pellet feed-box is empty. No pellet feed. The motor reducer does not feed pellets.	Check for the presence of pellets in the feed-box. Adjust the pellet flow (see "Pellet feed adjustment").
DEPR ALARM	The door is not closed correctly. The ash drawer is not closed correctly. The combustion chamber is dirty. The flue exhaust pipe is blocked	Check hermetic door closure. Check hermetic closure of the ash drawer. Check cleanliness of the fumes pipe and the combustion chamber.
DEBIMETER FAULT	Flow sensor faulty. Sensor disconnected	Contact after-sales centre
H20 OVERTEMP	Air in the system Unsuitable circulation	Possible air in the system, vent the system. Lack of adequate circulation. Lack of or inadequate safety zone. The water in the stove has exceeded 95°C. Possible circulator anomaly. If the problem persists, the reset operations must be carried out by an authorised technician.
TRAPDOOR FAULTY	Door not closed properly Burn pot dirty or clogged	Check closure of the door. Check that the burn pot is clear and clean. The automatic burn pot cleaning is blocked. If the problem persists contact the service centre
ALARM MINIMUM PRESSURE	The system pressure read by the pressure switch is too low.	Possible air in the system, vent the system. Possible lack of water or leaks due to anomalies in some system component. If the problem persists contact the service centre
ALARM H2O PROBE	H2O probe failure	Contact after-sales centre
ALARM MAX H2O PRESSURE	The pressure of the water has exceeded the max threshold	Possible air in the system, vent the system. Check that the expansion vessels are not damaged or under-dimensioned Check that the cold system is loaded at the correct pressure If the problem persists contact the service centre

Extraflame®

Riscaldamento a Pellet

Extraflame S.p.A. Via Dell'Artigianato, 12 36030 - MONTECCHIO PRECALCINO (VI) - ITALY
☏ +39.0445.865911 - 🖷 +39.0445.865912 - ✉ info@Extraflame.it - 💻 www.lanordica-Extraflame.com

The Manufacturer reserves the right to vary the features and data shown in this booklet at any time and without prior notice, in order to improve its products.
This manual cannot be considered as a contract for third parties.